

# CONTROL PANEL FOR DOUBLE/SINGLE SWING GATES 230V ac

## Instructions Manual



# Q81A



English

### Control panel for 230V ac operators – single and double leaf swing gates

- Automatic programming mode with obstacle detection
- Sequential programming mode: adjustable force, slow down, working time per single motor
- Immediate closing
- Pedestrian opening
- Multi-occupation feature
- Second radio channel interface (optional)
- Output for electrolock connection
- Ram blow and lock pulse function
- Removable radio receiver 433,92 MHz (32 codes) suitable for fixed or rolling code transmitters
- Input for 8K2 resistive safety edge
- Self diagnosis of malfunctions by LED coding

### TECHNICAL FEATURES

Item code	PQ81A, PQ81A1D
Pcb's dimensions	137 x 84 x 37 mm
Junction box dimensions	220 x 290 x 90 mm
Pcb's weight	160 g
Main Power supply	230V, 50-60 Hz
Power supply Tolerance	-10% +20%
Transformer	230/21Vac – 15VA
Main Fuse	5 A
Rated power	600 W
Max. power draw	3.5 A
Power draw in stand-by	30 mA
Blinker	24 Vac, max 20 W
Accessories	24 Vdc , max 5 W
Electrolock	12 Vdc, max 15 W
Operating temperature	-20 +50 °C
Protection rating	IP55

# Contents

1.	<b>SAFETY INSTRUCTIONS AND PRELIMINARY CHECKS</b> .....	<i>pag. 02</i>
2.	<b>DESCRIPTION AND MAIN COMPONENTS</b> .....	<i>pag. 03</i>
3.	<b>ELECTRICAL CONNECTIONS</b> .....	<i>pag. 04</i>
3.1	<b>MOTORS</b> .....	<i>pag. 06</i>
3.2	<b>MAIN POWER</b> .....	<i>pag. 07</i>
3.3	<b>START DEVICES</b> .....	<i>pag. 07</i>
3.3.1	TIMER wiring	
3.3.2	KEY-SWITCH wiring	
3.4	<b>PEDESTRIAN OPENING</b> .....	<i>pag. 07</i>
3.5	<b>EMERGENCY STOP BUTTON</b> .....	<i>pag. 08</i>
3.6	<b>PHOTOCELLS</b> .....	<i>pag. 08</i>
3.6.1	Photocells in CLOSING	
3.6.2	Photocells in OPENING	
3.7	<b>SAFETY EDGE</b> .....	<i>pag. 09</i>
3.7.1	Safety Edge in CLOSING	
3.7.2	Safety Edge in OPENING	
3.7.3	8K2 resistive safety edge in OPENING	
3.8	<b>FLASHING LIGHT</b> .....	<i>pag. 10</i>
3.9	<b>ELECTROLOCK</b> .....	<i>pag. 10</i>
3.10	<b>SECOND RADIO CHANNEL INTERFACE - SETTINGS</b> .....	<i>pag. 10</i>
3.10.1	Auxiliary radio channel .....	<i>pag. 11</i>
3.10.2	Signalling light	
3.10.3	CCourtesy light	
4.	<b>DEFAULT SETTINGS</b> .....	<i>pag. 12</i>
5.	<b>BROWSING THE MENU</b>	
5.1	<b>FUNCTIONS MENU</b>	
5.1.1	Automatic closing	
5.1.2	8K2 resistive safety edge input (just in opening)	
6.	<b>OPERATION MODE</b> .....	<i>pag. 13</i>
7.	<b>RADIO CODES</b> .....	<i>pag. 15</i>
7.1	<b>HOW TO DELETE EXISTING RADIO CODES</b>	
7.2	<b>HOW TO STORE A RADIO CODE FOR START COMMAND</b>	
7.3	<b>HOW TO STORE A RADIO CODE FOR PEDESTRIAN COMMAND</b>	
7.4	<b>HOW TO STORE A RADIO CODE FOR THE 2° AUXILIARY RADIO CHANNEL</b>	
8.	<b>PROGRAMMING</b> .....	<i>pag. 15</i>
8.1	<b>AUTOMATIC mode</b>	
8.1.1	Automatic mode with obstacle detection for DOUBLE LEAF GATES	
8.1.2	Automatic mode with obstacle detection for SINGLE LEAF GATES .....	<i>pag. 17</i>
8.2	<b>SEQUENTIAL mode</b> .....	<i>pag. 18</i>
8.2.1	Sequential mode with obstacle detection for DOUBLE LEAF GATES	
8.2.2	Sequential mode with obstacle detection for SINGLE LEAF GATES	
9.	<b>TROUBLE SHOOTING</b> .....	<i>pag. 19</i>

# 1. SAFETY INSTRUCTIONS AND PRELIMINARY CHECKS

**WARNING!** Important instructions for the safety of people, **READ CAREFULLY!**



Save this manual for future consultation.



Do not allow children to play with the fixed command devices, or in the gate's area of operation. Keep any remote control devices (i.e. transmitters) away from the children as well



Children are forbidden to carry out cleaning and maintenance unless accompanied by adults.



Children over 8 years, persons with reduced physical, sensorial, mental capabilities or unexperienced people are limited to use the operator unless accompanied by a supervisor or unless they get properly aware of potential hazards associated.



Always cut the power off before operating.

Make sure the earth connection is duly wired.

Wiring, installation and functional tests must be carried out by expert qualified personnel in full compliance with current regulation EN12453.

**Use of this control panel must be restricted to the transformer supplied by the Manufacturer.**

**A circuit breaker must be fitted close to the gate in compliance with the wiring diagram and installation instructions (see paragraph 3).**

**Stay clear of the gate's area of operation when in motion**

**Frequently check the system to see whether any anomalies or signs of wear and tear appear on the moving parts, on the component parts, on the securing points, on the cables and any accessible connections.**


**If the system requires repairs or modifications, release the operator and do not use it until safety conditions have been restored.**

This control panel is designed to automate single and double leaf gates. In case you wish to automate a single leaf.

**Gate be extremely careful to sections marked by this symbol**



## 2. DESCRIPTION AND MAIN COMPONENTS




- J1** = radio module
- J5** = input for electrolock or second radio channel jacks
- F2** = line fuse 230V 5A
- FR1** = self resettable fuse 24V 1,6A
- FR2** = self resettable fuse 24V 0,6A
- V1** = varistor secondary
- K2/K3** = motors relé
- K4** = flashing light relé
- TR2** = filter
- JP1** = GREEN TERMINAL - aerial connection
- JP2** = Secondary MOLEX card 24V ac
- JP3** = Primary MOLEX card 230V ac
- JP4** = BLUE TERMINAL – command devices
- JP5** = RED TERMINAL - line and photocells
- JP6** = YELLOW TERMINAL – flashing light
- JP7** = ORANGE TERMINAL - motor 1 (M1)
- JP8** = BLACK TERMINAL - motor 2 (M2)
- JP9** = GREEN TERMINAL – line 230V / earth
- SENS** = OBSTACLE DETECTION adjuster
- POWER** = THRUST adjuster
- SW1 - SW2** = FUNCTIONS SELECTION – dip switches mode

### PROGRAMMING BUTTONS

#### WARNING LED


- DL1** = PROGRAMMING
- DL2** = THRUST MOTOR 1
- DL3** = THRUST MOTOR 2
- DL4** = START
- DL5** = STOP
- DL6** = PEDESTRIAN START
- DL7** = PHOTOCELL IN CLOSING
- DL8** = PHOTOCELL IN OPENING



### 3. ELECTRICAL CONNECTIONS


#### WIRING DIAGRAM FOR 230Vac operators

**N.B.:**  
ALL SAFETY DEVICES MUST BE CONNECTED BEFORE STARTING PROGRAMMING, OTHERWISE THE CONTROL PANEL SHALL



**JP1** = Aerial connection


- 21 signal wire
- 22 earth wire



**JP2** = RED WIRES - secondary MOLEX card 24V dc




**JP3** = BLACK WIRES - primary MOLEX card 230V ac




**JP4** = BLUE TERMINAL – command devices

- 1 START (N.O. contact)
- 2 STOP (N.C. contact)
- 3 PEDESTRIAN (N.O. contact)
- 4 NEUTRAL




**JP5** = RED TERMINAL – line and photocells

- 5 5 photocell in closing (N.C. contact)
- 6 photocell in opening (N.C. contact)
- 7 RX photocells -24V
- 8 TX/RX +24V
- 9 TX photocells -24V




**JP6** = YELLOW TERMINAL – flashing light

- 10 flashing light 24V ac - max 20W
- 11 flashing light 24V ac - max 20W




**JP7** = ORANGE TERMINAL - MOTOR 1 (**M1**)

- 12 OPEN
  - 13 NEUTRAL
  - 14 CLOSE
- } MOTOR **M1**




**JP8** = ORANGE TERMINAL - MOTOR 2 (**M2**)

- 15 OPEN
  - 16 NEUTRAL
  - 17 CLOSE
- } MOTOR **M2**



**JP9** = GREEN TERMINAL - line 230V + earth

- 18 LINE
- 19 EARTH
- 20 NEUTRAL



Make sure a circuit breaker is properly fitted to the gate electric box.

**J5** = input for electrolock and second radio channel jacks



### 3.1 MOTORS WIRING

**M1** motor 1 → first to open and **last to close**

**M2** motor 2 → last to open and **first to close**

Connect motor 1 **M1** to **12 – 13 – 14**, terminal **JP7**.






















Connect motor 2 **M2** to **15 – 16 – 17**, terminal **JP8**.



① For single leaf gate, connect the motor to **12 – 13 – 14**, terminal **JP7**.

Proceed to wire the operator according to the below table:


**For ARTICULATED ARM OPERATORS disable the motors test – SWITCH 1 (SW1) DIP no. 4**

GATE TYPE	AUTOMATION MODEL		
	Traditional Ram 	Slimline Ram 	Underground motor 
Articulated ram motor 	Wheel-driven motor 		
Left leaf 1st opening (M1) 			
Right leaf 1st opening (M1) 			
Left leaf (M1) 			
Right leaf (M1) 			

## 3.2 MAIN POWER

The main line must be protected by a proper **CIRCUIT BREAKER**.


Connect the line 230V to **18 - 19 - 20**, terminal **JP9**, fulfilling the polarity (18 PHASE - 19 EARTH - 20 NEUTRAL).



## 3.3 START DEVICES

Wire the START contact (N.O. contact) to **1 - 4**, terminal **JP4**.

An additional START contact can be wired in **PARALLEL** (N.O. contact)




### 3.3.1 TIMER

It is possible to wire a TIMER (N.O. contact) to **1 - 4**, terminal **JP4**.


#### WARNING:

when connecting a TIMER, the multi-users function must be enabled. SW1 DIP 2 = ON



### 3.3.2 KEY SWITCH


Wire the KEY SWITCH (N.O. contact) to **1 - 4**, terminal **JP4**.



## 3.4 PEDESTRIAN OPENING

Wire the PEDESTRIAN START (N.O. contact) to **3-4**, terminal **JP4**.

An additional PEDESTRIAN START contact can be wired in PARALLEL (N.O. contact)





### 3.5 EMERGENCY STOP BUTTON


Wire the STOP BUTTON (N.C. contact) to **2 - 4**, terminal **JP4**.  
An additional STOP BUTTON contact can be wired in **SERIES** (N.C. contact).



**The EMERGENCY STOP BUTTON is important for the safety of people and objects**

N.B.: To disable the STOP BUTTON during installation, **plug 2 and 4 together**.

Note: Before wiring any STOP contact remove the jumper between **terminal 2 and terminal 4**.



### 3.6 PHOTOCELLS

#### 3.6.1 Photocells IN CLOSING



Feed the photocells through **7-8-9**, terminal **JP5**.  
Wire the photocell contact (N.C. contact) to **5-7**, terminal **JP5**.  
An additional photocell set can be wired in **SERIES** (N.C. contact).

- If the photocell beam is broken during CLOSING, the gate **stops and reverses after 1,5 sec.**
- If the photocell beam is broken during OPENING, the gate keeps on working normally.



**The PHOTOCELLS IN CLOSING are important for the safety of people and objects.**

N.B.: To disable the photocell in closing during installation, **plug 5 and 9 together**.



#### 3.6.2 Photocells in OPENING


Feed the photocells through **7-8-9**, terminal **JP5**.  
Wire the photocell contact (N.C. contact) to **6-7**, terminal **JP5**.  
An additional photocell set can be wired in **SERIES** (N.C. contact).

- If the photocell beam is broken during OPENING, the gate **stops temporarily**.
- When the photocell beam is free, the gate **goes to normal operation**.



**The PHOTOCELLS IN OPENING are important for the safety of people and objects.**

Nota: Before wiring any PHOTOCCELL in OPENING, remove the jumper between **terminal 6 and terminal 9**.



### 3.7 SAFETY EDGE

#### 3.7.1 Mechanical safety edge in CLOSING



Wire the safety edge to **5-9**, terminal **JP5**.

- If the contact is broken during **CLOSING**, the gate stops and reverses.
- If the contact is broken during **OPENING**, the gate keeps on working normally

#### Mechanical safety edge + photocells in CLOSING

Wire the safety edge and the N.C. contact of the photocell in series.

- If the contact is broken during **CLOSING**, the gate stops and reverses.
- If the contact is broken during **OPENING**, the gate keeps on working normally



#### 3.7.2 Mechanical safety edge in OPENING

Wire the safety edge to **6-9**, terminal **JP5**.

- If the contact is broken during **OPENING**, the gate stops and reverses after 3 sec.
- If the beam is broken during **CLOSING**, the gate stops and reverses.

**N.B.: Attention!**

Proceed to set **SW2 dip-switch no. 2 = ON**.



#### Mechanical safety edge + photocells in OPENING

Wire the safety edge and the N.C. contact of the photocell in series.

- If the beam is broken during **OPENING**, the gate stops until the obstacle is removed and then starts opening again.
- If the beam is broken during **CLOSING**, the gate stops and reverses.

**N.B.: Attention!**

Adjust **SW2 dip-switch no. 2 = OFF**



### 3.7.3 8K2 resistive safety edge in OPENING


- Adjust **SW2 dip-switch no. 2 = ON**
  - Press **SET + SET TX** together and feed the control panel.
- Wire the 8K2 safety edge to **6 - 9**, terminal **JP5**.

- If the contact is broken during **OPENING**, the gate stops and reverses after 3 sec.
- If the beam is broken during **CLOSING**, the gate stops and reverses.

### 8K2 safety edge + photocells in OPENING

- Adjust **SW2 dip-switch no. 2 = ON**
  - Press **SET + SET TX** together and feed the control panel.
- Wire the safety edge and the N.C. contact of the photocell in series.


- If the contact is broken during **OPENING**, the gate stops and reverses after 3 sec.
- If the beam is broken during **CLOSING**, the gate stops and reverses.



### 3.8 FLASHING LIGHT

Wire the flashing light (max 20W) to **10 – 11**, terminal **JP6**.

- QUICK blinking → OPEN
- SLOW blinking → CLOSE
- FIXED light on → PAUSE





### 3.9 ELECTROLOCK



**ATTENTION:**  
**CUT THE POWER OFF BEFORE PLUGGING THE JACK**

Plug the **MEL04** interface (optional) onto connector **J5**, respecting the slot orientation.

Wire the ELECTROLOCK to **MEL04**.



### HOW TO PLUG THE 2nd RADIO CHANNEL INTERFACE






**ATTENTION:**  
**CUT THE POWER OFF BEFORE PLUGGING THE JACK**

Plug the **MRX01** jack (optional) onto connector **J5**, respecting the slot orientation.



Before setting the dip-switch **SW1**, make sure the power is off.



contact **N.O.**  
max **1A - 24V**

### 3.10.1 Auxiliary radio channel AUX

To use the **MRX01** interface as second radio channel, proceed this way:


#### ATTENTION: Quite siempre la tensión antes de cambiar la posición de los Dip-switch

##### MONOSTABLE COMMAND

The contact **ACTIVATES** when giving a start command by the remote control.

If you wish to choose this function mode, select the switches as follows:

**1 = ON                      2 = OFF                      3 = OFF                      4 = NO EFFECT**




##### BISTABLE COMMAND

The contact **ACTIVATES** or **DESACTIVATES** every time you press the remote control.

If you wish to choose this function mode, select the switches as follows:

**P1 = OFF                      2 = ON                      3 = OFF                      4 = NO EFFECT**



##### TIMED COMMAND

The contact **ACTIVATES** when giving a start command by the remote control and stays for 90 seconds.

If you wish to choose this function mode, select the switches as follows:

**1 = ON                      2 = ON                      3 = OFF                      4 = NO EFFECT**



### 3.10.2 Signalling LIGHT

The contact **ACTIVATES** at **OPENING** and **DESACTIVATES** only at **FINAL CLOSING POSITION**.

If you wish to choose this function mode, select the switches as follows:

**1 = OFF                      2 = OFF                      3 = ON                      4 = NO EFFECT**




### 3.10.3 Courtesy LIGHT

The contact **ACTIVATES** at **OPENING** and **DESACTIVATES** after 90 from complete duty cycle.

If you wish to choose this function mode, select the switches as follows:


**1 = ON                      2 = OFF                      3 = ON                      4 = NO EFFECT**



#### Nota:

The control panel can connect a maximum of 2 jacks at once.

Plug the jacks one onto the other as shown in the picture, carefully following the slot post.



## 4. DEFAULT SETTINGS

The control panel is supplied with a **DEFAULT SETTINGS**: working time and delay are set for a standard 90° opening.

To reload the **DEFAULT SETTINGS**:

- Press **BREAK** to cut the power OFF and ON
- Turn **SENS** to the maximum (+) and **POWER** to half position.

## 5. BROWSING THE MENU



SET



SET TX

### SET

Use **SET**:

- To program the control panel (section **8.1. AUTOMATIC MODE** – **8.2. SEQUENTIAL MODE**).
- To activate or deactivate the automatic closing (section **5.1.1**)



WORK



BREAK



SET



SET TX

### SET TX

Use **SET TX**:

- To store or to delete a radio code.



WORK



BREAK



SET



SET TX

### WORK

Use **WORK**:

- As **START** command
- For **SEQUENTIAL PROGRAMMING**



WORK



BREAK



SET



SET TX

### TASTO BREAK

Use **BREAK**:

- To activate and set the **AUTOMATIC CLOSING TIME** (section **5.1.1**)



WORK



BREAK

## 5.1 FUNCTIONS MENU

### 5.1.1 AUTOMATIC CLOSING

The **AUTOMATIC CLOSING DEFAULT** is set at 3 sec.

To set the **AUTOMATIC CLOSING TIME**:

- Press **SET** for 3 sec. **DL1** blinks, release **SET**.
- Press **BREAK** and release.
- The blinker and led **DL1** light up, the control panel starts the count down.
- Press **BREAK** again when reached the desired time, the blinker turns off.  
The time has been set (automatic closing time max. 120 sec.)

To deactivate the **AUTOMATIC CLOSING**:


- Press **SET** for 3 sec. and release, the led **DL1** blinks.
- Press **BREAK** and hold for 5 sec., the **AUTOMATIC CLOSING** has been deactivated

### 5.1.2 8K2 RESISTIVE SAFETY EDGE INPUT (just in opening)

To activate the **8K2** input as safety in opening press **SET + SET TX** while turning the control panel on.

## 6. OPERATION MODE

Choose the operation mode you wish selecting the switches SW1 – SW2.  
The control panel is supplied with the following default settings:



How to  
read switch  
position:



WHITE switch **DOWNWARD** = Function **OFF**



WHITE switch **UPWARD** = Function **ON**



**ATTENTION: Turn the power off before setting the switches**

**SWITCH SW1**  
dip n° 1



ON

OFF = Double-leaf gate mode



ON = Single-leaf gate mode


OFF

dip n° 2



ON

OFF = Multi-occupation mode **DEACTIVATED**



ON = Multi-occupation mode **ACTIVATED**

OFF

This function gives priority to the first open command. The control unit won't accept additional START commands during OPENING and AUTOMATIC CLOSING COUNT DOWN.

dip n° 3



ON

OFF = **Soft start mode DEACTIVATED**

At opening motors work at the set thrust (**POWER**)



ON = **Soft start mode ACTIVATED**

At opening motors perform at maximum thrust for 1,5 sec., to continue after at the set thrust.

OFF

dip n° 4



ON

OFF = **Motor and photocell TEST DEACTIVATED**



ON = **Motor and photocell TEST ACTIVATED**

OFF

## SWITCH SW2

### dip n° 1



ON

OFF = Ram blow and closing thrust DEACTIVATED



ON = Ram blow and closing thrust ACTIVATED (just for gates with electrolock)


OFF

### dip n° 2



ON

OFF = Photocell in OPENING ACTIVATED



ON = Mechanical safety edge ACTIVATED  
8K2 resistive safety edge ACTIVATED.

N.B.: It's mandatory to carry out the INPUT TEST


OFF

### dip n° 3



ON

OFF = Immediate closing mode DEACTIVATED



ON = Immediate closing mode ACTIVATED

The gate starts CLOSING after 1,5 sec.  
bypassing the AUTOMATIC CLOSING COUNT DOWN

OFF

### dip n° 4



ON

OFF = Ram stroke RELEASE mode DEACTIVATED



ON = Ram stroke RELEASE mode ACTIVATED

At the endpoint stage during CLOSING and OPENING, the motors press onto the mechanical endstop, cut the thrust, and release a small space between the doors for safety operation.

OFF



## 7. RADIO CODES

The control panel **DOESN'T ALLOW TO STORE** any remote control if **SAFETY DEVICES** are **DISCONNECTED**.

Make sure input no. **2 STOP (DL5)**, input no. **5 photocell in OPENING (DL7)** and input no. **6 photocell in CLOSING (DL8)** are connected.

**Led OFF** = input **DEACTIVATED**

**Led ON** = input **ACTIVED**

If no safety device has been wired, proceed to bridge temporarily the terminal according to chapter **3.6.1**.

The control panel has been designed to operate with fixed code or rolling-code remote controls. Choose the remote control you wish to store carefully: once the remote control has been saved and memorized, the control panel shall only recognize that kind of radio code without possibility of reset.

**Before starting proceed to delete all existing radio codes.**

### 7.1 DELETING EXISTING RADIO CODES

- Press **SET-TX** and keep pressed for 10 seconds (**DL1** blinks).
- **DL1** turns off. **All codes have been deleted.**

### 7.2 LOADING A REMOTE CONTROL AS START COMMAND

- Press **SET-TX** once: **DL1** blinks (1 blink – stop – 1 blink ....)
- Load within 5 sec. the remote control you wish to store.

**The control panel has stored the radio code and goes out the programming automatically.**

You can store a maximum of 32 different radio codes (Start + Pedestrian + 2° radio channel)

### 7.3 LOADING A REMOTE CONTROL AS PEDESTRIAN COMMAND

- Press **SET-TX** twice. **DL1** blinks (2 blinks – stop – 2 blinks ....)
- Load within 5 sec. the remote control you wish to store.

**The control panel has stored the radio code and goes out the programming automatically.**

### 7.4 LOADING A REMOTE CONTROL AS 2° RADIO CHANNEL COMMAND (MRX01 jack)

- Press **SET-TX** three times. **DL2** blinks (3 blinks – stop – 3 blinks ....)
- Load within 5 sec. the remote control you wish to store.

**The control panel has stored the radio code and goes out the programming automatically.**

## 8. PROGRAMMING

The control panel is supplied with a **SEQUENTIAL PROGRAMMING DEFAULT** (obstacle detection excluded)

### 8.1 AUTOMATIC mode

#### 8.1.1 AUTOMATIC mode with OBSTACLE DETECTION for double-leaf gates

##### ATTENTION!:

Before proceeding to programming, start a functional cycle test to proof the motors' thrust.

The thrust has to be proper to the gate weight no matters if light or heavy gates.

If adjustments are needed, regulate POWER so that the gate doesn't stop opposing a light contrast pressure.

- Start programming with cool operators.
- The AUTOMATIC MODE PROGRAMMING can only perform if mechanical ground endstops are fitted, in Opening and Closing.

- Gate in **CLOSING POSITION**.
- **SENS** in half position.
- If during programming the gates stop before reaching the ground endstops, turn **SENS** (sensitivity) clockwise (to +).
- Press SET and keep pressed for 10 sec., **DL1** starts blinking.
- When motors start working release **SET**.
- Motors run firstly a short **OPENING** for 4 sec., **M1 first** and **M2 after** (delayed leaf), then **CLOSE** until the ground mechanical endstop in closing.
- At this stage the gate performs an **OPENING RUN** until fully open and a **CLOSING RUN** until fully close.
- When the procedure is finished, all time settings are saved.  
The control panel is now ready for normal operation.

##### ATTENTION!:

Check the proper **GATE OPERATION SENSITIVITY**.

If adjustments are needed, turn **SENS** clockwise (to +) and regulate accordingly.

The sensitivity has to be proper in order to prevent uncorrect operation

#### OBSTACLE DETECTION OPERATION

- If an obstacle is detected in opening, **the gate stops and reverses for 10 cm**.
- The gate **starts closing automatically after 30 sec.**, and this will be for 3 attempts.  
If the area still remains unclear the gate stays open.
- If an obstacle is detected during slow down, **the gate simply stops**.
- If an obstacle is detected in closing, **the gate stops and reverses till fully open**.
- The gate **starts closing automatically after 30 sec.**, and this will be for 3 attempts. If the area still remains unclear the gate stays open.
- If an obstacle is detected during slow down, **the gate simply stops**.
- If power cut occurs, **the first START cycle will perform without obstacle detection** just to restore properly the standard operation of the gate.

### 8.1.2 AUTOMATIC mode with OBSTACLE DETECTION for single-leaf gates

**ATTENTION!:**

The motor has to be wired to M1 input (orange terminal JP7, blocks 12 – 13 – 14)

- Switch **SW1**, dip no. **1 = ON**.
- Gate in **CLOSING** position.
- **SENS** in half position.
- If during programming the gates stop before reaching the ground endstops, turn **SENS** (sensitivity) clockwise (to +).
- Press **SET** and keep pressed for 10 sec., **DL1** starts blinking.
- When motor starts working release **SET**.
- Motor runs firstly a short **OPENING** for 4 sec., **M1** first and **M2** after (delayed leaf), then **CLOSE** until the ground mechanical endstop in closing.
- At this stage the gate performs an **OPENING RUN** until fully open and a **CLOSING RUN** until fully close.
- When the procedure is finished, all time settings are saved.  
The control panel is now ready for normal operation.

**ATTENTION!:**

Check the proper **GATE OPERATION SENSITIVITY**.

If adjustments are needed, turn **SENS** clockwise (to +) and regulate accordingly.

The sensitivity has to be proper in order to prevent uncorrect operation.

## 8.2.1 SEQUENTIAL mode WITHOUT Obstacle Detection for double-leaf gates

**ATTENTION!**

Before proceeding to programming, start a functional cycle test to proof the motors' thrust. The thrust has to be proper to the gate weight no matters if light or heavy gates. If adjustments are needed, regulate POWER so that the gate doesn't stop opposing a light contrast pressure.

- Start programming with cool operators.
- The AUTOMATIC MODE PROGRAMMING can only perform if mechanical ground endstops are fitted, in Opening and Closing.

- **SENS** in maximum position (to +)
- Programming can be carried out both **with the remote control or WORK button**.
- Press **TEST** for 3 sec., **DL1** starts blinking, release.
- Press the button of the remote control previously loaded. **M1 motor STARTS OPENING**.
- At 80% of opening press the remote control to start **SLOW DOWN**.
- When fully open let the motor run for 3/4 sec., then press the remote control again.
- Now **M1 settings are LOADED**.
- Press the remote control, the control panel starts counting the **DELAY TIME in opening** (max. 20 sec.)
- Press the remote control again to set the desired delay time (standard operation 2/3 sec.)
- Now the **DELAY TIME** in opening is loaded. **M2 motor STARTS OPENING**.
- At 80% of opening press the remote control to start SLOW DOWN.
- When fully open let the motor run for 3/4 sec., then press the remote control.
- Now **M2 settings are LOADED**.
- Press the remote control, **M2 motor STARTS CLOSING**.
- Press the remote control, the control panel starts counting the **DELAY TIME in closing** (max. 20 sec.)
- Press the remote control again to set the desired delay time (standard operation 2/3 sec.)
- **Now M1 motor starts automatically closing**.
- Let gates complete the closing run.
- When the procedure is finished, all time settings are saved.  
The control panel is now ready for normal operation

**Check the good operation of the gate. If time settings need to be adjusted go back to programming and repeat the whole programming procedure.**

## 8.2.2 SEQUENTIAL mode WITHOUT Obstacle Detection for single-leaf gates

- **SENS** in maximum position (to +)
- Programming can be carried out both **with the remote control or WORK button**.
- Press **TEST** for 3 sec., **DL1** starts blinking, release.
- Press the button of the remote control previously loaded. **M1 motor STARTS OPENING**.
- At 80% of opening press the remote control to start **SLOW DOWN**.
- When fully open let the motor run for 3/4 sec., then press the remote control again.
- Now **M1 settings are LOADED** and the motor **starts CLOSING**.
- Let gate completes the closing run.
- When the procedure is finished, all time settings are saved.  
The control panel is now ready for normal operation

**Check the good operation of the gate.  
If time settings need to be adjusted go back to programming and repeat the whole programming procedure.**

## 9. TROUBLE SHOOTING – ERROR MESSAGES

The control panel is designed to display errors through a LED lighting system.  
Here below the trouble shooting table.

Led	ERROR	POSSIBLE CAUSE	SOLUTION
DL1 + blinker	2 blinks stop 2 blinks ....	• <b>Photocell test</b>	Check the wiring and operation of the photocell.
	3 blinks stop 3 blinks ....	• <b>Motor test</b>	Check the wiring and operation of the motors.
	OFF	• Power supply disconnected	Check the connection to the power supply
DL4	ON	• Permanent <b>START</b> command	Check the operation of the ACCESSORIES wired to the START (N.O. contact)
DL5	OFF	• STOP button disconnected	Check the wiring otherwise (see section 3.5)
		• Incorrect electric wiring	Check the wiring diagram (see section 3.5)
DL7	OFF	• Photocell in closing non-aligned	Check the photocell alignment
		• Obstacle detected between the photocells	Check and remove the obstacle
		• Incorrect electric wiring	Check the wiring diagram
		• Disconnected photocell	Check the power connection
		• Disconnected photocell, active input	Disable the photocell input (see section 3.6)
DL8	OFF	• Photocell in opening non-aligned	Check the photocell alignment
		• Obstacle detected between the photocells	Check and remove the obstacle
		• Incorrect electric wiring	Check the wiring diagram
		• Disconnected photocell	Check the power connection
DL6	ON	• Permanent PEDESTRIAN command	Check the operation of the ACCESSORIES wired to the PEDESTRIAN START (N.O. contact)

Il nostro Servizio Assistenza è a tua disposizione  
per qualsiasi chiarimento  
sul prodotto, sull'installazione o sulla garanzia:  
dal Lunedì al Venerdì, dalle 8.30 alle 12.00 e dalle 13.30 alle 17.00



346/4192300



info@mygateautomation.com

